

Quick start installation instructions for the disinfection Resonator sprayer.

For more information please go through the entire manual.



Step 1

1.1 Mount the Resonator atomizer at the height indicated on the atomizer sticker. The atomizer always mount as shown!



Step 2

2.1 Fit the suction line from the sprayer to the place where the tank will be placed

2.2 Drill a hole 6.5 millimeters in the tank cap.

2.3 Fit the suction line through the cap.

2.4 Apply the tape in this way, in four layers without any unevenness to the suction line



Step 3

3.1 Lubricate the tape and the inside of the silicone tubing.

3.2 Then press the silicone tube over the tape



Step 4

4.1 Pull the M12 nut on the silicone hose at the location of the tape as shown in picture. The suction pipe from the tank is then ready.



Step 5

5.1 Cut the suction tube to the correct length to the suction coupling to the side of the sprayer.

5.2 Bring to the sprayer side the nut over the suction line.

5.3 Press the hose at the fluid coupling.



Step 6

6.1 Turn the nut to the clutch and turn to fix it by hand.

That is simpler and sufficient to create a good connection.

READY FOR USE!